

# Printhead Cleaning




Label printer manufacturers recommend to **clean the printhead** of a POS, card or label printer with every 2-3 rolls of labels or ribbons.

## Why do you care?

- 1 Prevent premature printhead failure
- 2 Produce high-quality images


**Save money.** The printhead is the most expensive consumable in your label printer and it can cause the most print-related issues. By cleaning it, you will get a longer life out of your printhead.

**Ink residue, dirt and adhesive build-up will result in poor print quality, or worse.** The cost of unreadable barcodes differs by industry and may include fines or issues down the supply chain.



## How to clean a printhead and platen roller

If you maintain a printhead well, there's no need for scraping or other harsh measures. Open the printer and simply wipe it down with a cleaning pen, wipe or swab.



**Release the printhead and allow it to cool**



**Wipe the printhead with a pen, wipe or swab**



**Wipe the platen roller (do NOT use a cleaning pen!)**

# Printhead Cleaning



## What is the right **cleaning product**?

Printhead cleaning products come in various shapes and forms. You have a choice of cleaning pens, swabs, cards and wipers. What's best for you depends largely on your experience and preference. Often, a combination of products works best. For example, a saturated swab to clean the printhead and a wipe for the platenroller. Manufacturers recommend printhead cleaning with pure Isopropyl alcohol, which actively cleans and evaporates quickly after application. This means that you are back to printing right after a cleaning.



### **4U-Wipe-40**

40 individually sealed saturated wipes

Contains 80% Isopropyl Alcohol

**Size wipe:** 150 mm x 100 mm (5.91 x 3.94 inch)



### **4U-Wipe dispenser-100**

100 saturated wipers in a container

Contains 70% Isopropyl Alcohol

**Size wipe:** 178mm x 135mm (7 x 5.3 inch)



### **4U-Pen-10**

10 alcohol-filled pens

Contains 80% Isopropyl Alcohol

**Size pen:** 140mm (5.5 inch)



### **4U-ISO swab-25**

25 alcohol-filled swabs

Contains 99.7% Isopropyl alcohol

**Size swab:** 113mm (4.4 inch)



### **4U-SAT swab-15**

15 individually sealed saturated swabs

Contains 99.7% Isopropyl alcohol

**Size swab:** 127mm (5 inch)